

A-CLR-ANCR-4 – Collar – Hose Support – Split Clamp

SKU: A-CLR-ANCR-4



Description

- The support collar is designed to fit around the split clamp that connects a male and female hose coupling. One of its ear shackles attaches to an anchor while the other attaches to a float. The collars are used to support a hose assembly running from sea to shore.

Specification Table

hose_size	'4
drawing_number	C21357
Material	Aluminum/Steel